















<p><b>Record your model number.</b></p>	<p><b>Important Information</b> Observe all local plumbing and building codes.</p>	<p><b>1</b> Determine the valve stem adapter length. Refer to the plaster guard.</p> 	<p><b>Thin Wall:</b> Use the #3 adapter and the 13/16" (21 mm) screw.</p> 	<p><b>Standard Wall:</b> Use the #1 adapter and the 13/16" (21 mm) screw.</p> 
<p><b>Thick Wall:</b> Use the #2 adapter and the 1-3/8" (35 mm) screw.</p> 	<p><b>2</b> Remove the plaster guard. Place the spline adapter on the valve stem.</p> 	<p><b>3</b> Temporarily fit the valve stem adapter on the spline adapter.</p> 	<p><b>4</b> Position the handle on the valve stem adapter.</p> 	<p><b>5</b> Water will flow from a single shower accessory when the control knob detent lines up with any of the large detents on the escutcheon, or from two accessories when the control knob is centered between two large detents on the escutcheon.</p> 
<p><b>6</b> Water should flow from accessory "A" with the handle position at 12 o'clock.</p> 	<p><b>7</b> To adjust position, remove the handle and valve stem adapter. Turn the spline adapter.</p> 	<p><b>8</b> Secure the valve stem adapter with the proper length screw.</p> 	<p><b>9</b> Secure the plate assembly to the valve with proper length screws. <b>Do not overtighten.</b></p> 	<p><b>10</b> Fit the faceplate over the plate assembly with the notch down.</p> 
<p><b>11</b> Point the handle downward. Thread the bonnet onto the hub.</p> 				

Questions? Problems? For additional assistance, please contact  
KALLISTA's Customer Service Department at 1-888-4-KALLISTA  
(1-888-452-5547) or [kallista.com](http://kallista.com).